

Function number	Test Station	Percent	Faults	Percent
PERFRM OPERATION	18	94.7	76	100.0
BASIC FUNCTIONS:	10	52.6	17	22.4
010000 FURNISH POWER	3	15.8	5	6.6
011000 SUPPLY FUEL	1	5.3	3	3.9
013000 CONVERT ENERGY	2	10.5	2	2.6
020000 PROPEL VEHICLE	3	15.8	3	3.9
022000 TRANSFER TORQUE	2	10.5	2	2.6
023000 ENGAGE TRACTION	1	5.3	1	1.3
030000 CONTROL MOVEMENT	6	31.6	7	9.2
031000 POSITION OPERATR	1	5.3	1	1.3
032000 CONTROL SPEED	1	5.3	1	1.3
033000 CONTRL DIRECTION	4	21.1	4	5.3
040000 POWER MACHINERY	2	10.5	2	2.6
SUPPORTING FUNCTIONS:	18	94.7	59	77.6
050000 ASSR CONVENIENCE	4	21.1	4	5.3
053000 AID SERVICE	4	21.1	4	5.3
053100 FACLITATE ACCESS	1	5.3	1	1.3
053200 SIMPLIFY SERVICE	3	15.8	3	3.9
060000 ASSR DEPNDABILTY	15	78.9	31	40.8
061000 PREVENT DAMAGE	9	47.4	10	13.2
061300 RESIST BREAKAGE	8	42.1	8	10.5
061600 WARN OPERATOR	1	5.3	1	1.3
062000 MAINTAIN TASK	11	57.9	15	19.7
062100 ENSURE START	1	5.3	1	1.3
062300 REDUCE WEAR	6	31.6	6	7.9

<u>Function number</u>	<u>Test Station</u>	<u>Percent</u>	<u>Faults</u>	<u>Percent</u>	
064000	PROTECT CROP	2	10.5	2	2.6
064100	ADJUST TRACKS	1	5.3	1	1.3
064200	ASSURE CLEARANCE	1	5.3	1	1.3
065000	PROTECT PERSONS	1	5.3	1	1.3
067000	PROTECT ENVIRONMENT	3	15.8	3	3.9
067100	REDUCE EMISSION	1	5.3	1	1.3
067200	ELIMINATE LEAKS	2	10.5	2	2.6
070000	SATISFY USER	11	57.9	24	31.6
071000	INCREASE COMFORT	8	42.1	11	14.5
071400	ENTERTAIN OPERATOR	1	5.3	1	1.3
071500	ABSORB SHOCK	6	31.6	7	9.2
072000	FACILITATE OPERATIONS	3	15.8	4	5.3
072100	INCREASE VISIBILITY	2	10.5	2	2.6
072200	REDUCE EFFORT	1	5.3	1	1.3
074000	CONSERVE FUEL	6	31.6	9	11.8